

Verarbeitungsanleitung für Lack-Stick W-686-9006/-9007/-7070

- 1) Ziehen Sie den Schöpfzylinder aus dem Schraubverschluss und entnehmen Sie damit die nötige Pulvermenge zum Mischen.
 - 2) Entfernen Sie den Schraubverschluss und leeren Sie das Pulver aus dem Schöpfzylinder in den Metallbehälter.
 - 3) Verschließen Sie den Metallbehälter und schütteln Sie mindestens 0,5 - 1 Minute den Stick.
 - 4) Mit dem Pinsel kleine Stellen austupfen und dann verstreichen.
- ACHTUNG: Verarbeitungszeit je nach Lagertemperatur 1 - 2 Tage

User Instruction for Lacquer stick W-686-9006/-9007/-7070

- 1) Disconnect the scoop cylinder from the screw cap and put the required amount of powder for mixing out of the bag.
 - 2) Remove the screw cap and empty the powder from the scoop cylinder into the metal container.
 - 3) Close the metal container and shake the lacquer stick at least 0,5 - 1 minute long.
 - 4) Repair the small sports concerned by using the brush and then elapse the lacquer.
- CAUTION: processing time depending on storage temperature 1 - 2 days

